mpman

For series /

MP724
MP824
MP1024

Internet Tablet
Quick Start Guide

Please read this instruction carefully before the operation

Table of Contents

English

THANK YOU 3
Package Contents 3
Features 4

GETTING TO KNOW THE INTERNET TABLET 5
About the Touchscreen 8
Protective Film 8
Using the Stylus (MP724 & MP824) 8
Touchscreen Actions 8
About the Orientation Sensor 10
Charging the Tablet 10
Inserting a Memory Card 11

GETTING STARTED 12
Turning the Tablet on and off 12
Turning the Screen On and Off (Standby) 13
Unlocking the Screen 13
Home Screen at a Glance 14
About Applications 15
Preinstalled Applications 16
Installing Applications 17
About Menus 17
About Notifications 19

CONNECTING TO THE INTERNET 20
Requirements 20
Connect to a Wi-Fi network 21

BROWSING THE WEB 23

MANAGING APPLICATIONS 27

OPTIONAL CONNECTIONS 30
Connecting to a Computer 30
Connecting to a TV 31
Connecting Headphones 32
Using the USB Full-Size Adapter 33
Connecting a Keyboard 33
Connecting a Storage Device 33

SETTING THE SYSTEM OPTIONS 34

SPECIFICATIONS 35

Thank You

Congratulations on your purchase of the Internet Tablet. This guide is provided to help you get started quickly with your player; please read it carefully and save it for future reference.

Package Contents

Please make sure that the items shown below are included in the package. Should an item be missing, please contact the local retailer from which you purchased this product.

- Internet Tablet
- Protective pouch
- Stylus (MP724 & MP824 only)
- USB cable
- USB host/keyboard adapter
- Professional stereo Earphones
- Power adapter

This package may contain plastic bags or other materials that pose a hazard to children. Be sure to safely dispose of all packing materials after opening.

Features

- Browse the Web.
  Visit your favorite websites
- Check your e-mail
  Keep in touch with friends and family
- Watch YouTube™ videos
  Browse the world's most popular video-sharing community
- Read your favorite books
  Download thousands of books with the included Aldiko E-book reader *
- Discover thousands of apps for Android™
  Download apps from AppsLib—the marketplace designed for tablets
- Connect to the Internet wirelessly
  High-speed Wi-Fi 802.11 b/g networking
- HDMI™ output to your TV **
  Enjoy videos, photos and more in the comfort of your living room
- Enjoy your media library anywhere
  Portable powerhouse plays popular music, video, and photo formats
- microSD memory card reader
  Increase your storage capacity (up to 32 GB supported)
- Built-in camera
  Convenient front-facing camera
- Automatic orientation detection
  Read any way you want; the display adjusts automatically!

* Reading books in the ePub format requires the included Aldiko E-book reader application.

** Requires optional HDMI cable (Type A-to-Type C). 1080p HD video playback requires a video file encoded at 1080p. Streaming video quality will be affected by the source, and the quality and condition of your network connection.

Getting to Know the Internet Tablet

Unit at a Glance

Name		Description
1	Volume + key	Press to increase the volume level.
2	Volume – key	Press to decrease the volume level.
3	Power key	Press to turn the unit on, or to turn the screen on and off. Press and hold to access the Power Off menu.
4	Speakers	Stereo speakers.



Name		Description
5	Camera	Front-facing camera
6	**Search** soft key	Tap to search with Google.
7	**Back** soft key	Tap to return to the previous screen. If the keyboard is on the screen, tap to close the keyboard.
8	**Home** soft key	Tap to return to the home screen. Tap and hold to view a list of recently used applications; touch an application in the list to launch it.
9	**Menu** soft Key	Tap to view the option menu. *Note: When you Tap the **Menu** key from within an application, you will see the options for that application. To view the Android system options, tap the **Menu** key from the home screen.*
10	**Browser** soft Key	Tap to launch the Browser to visit your favorite websites.



Name		Description
11	microSD card slot	Load external microSD memory cards here.
12	**Reset** key	Press to reset the tablet if it freezes or otherwise behaves abnormally. (Use a paperclip or other small object to gently press this key.)
13	Power jack (DC input)	Charge and power the tablet with the included power adapter.
14	USB 2.0 Hi-speed port	Connect to a computer to transfer data (e.g., music, videos, photos, files).
15	Headphone jack	Audio output connection for headphones. *Note: Speaker output is automatically disabled when headphones are connected to the player.*
16	HDMI jack (mini Type C)	Connect to a TV or other display.



English

About the Touchscreen

Your tablet comes equipped with an easy-to-use touch-screen which allows access to the tablet's functions. Use your finger tip to touch the area of the screen where a control icon is displayed. If you touch and hold the screen, it will register as a continuous button press.

To avoid damaging the screen, do not touch it with excessive force or with any object other than your finger (or a stylus). For best response, make sure your hands are clean before using the touchscreen controls.

Protective Film

A thin film has been applied to the touchscreen to protect it during shipping. The protective film should be removed before use. To remove it, simply take a corner of the film and peel it away from the screen.

Using the Stylus (MP724 & MP824)

A stylus is included for your convenience. You can use the tip of the stylus to make precise selections on the touchscreen.

The MP1024 will not work with a stylus; you must use your finger to operate its touchscreen.

Touchscreen Actions

You can control the functions of the tablet by using the touchscreen in combination with the three touch keys located on the bezel. To control the tablet with the touchscreen, use your fingertip or stylus to manipulate icons, buttons, menu items, the on-screen keyboard, and other items displayed on the screen.

You can perform the following actions on the touchscreen using your fingertip or stylus.

Touch:	To activate an on-screen item (e.g., application icons, buttons, menu items, and the letter/symbols of the on-screen keyboard), simply touch them with your fingertip or stylus.

Touch and Hold:	Some on-screen items have an alternate action if you touch and hold it (e.g., opening an alternate menu, or to activate the drag function). To touch and hold an item, touch the item and do not lift your fingertip/stylus until the action occurs.
Drag:	Drag an on-screen item to change its position (e.g., an application icon on the home screen). To drag an item, touch and hold it for a moment, then without lifting your fingertip/stylus, move your fingertip/stylus on the screen until the item reaches its target destination.
Swipe:	Swipe up/down on the screen to scroll through a list. On some screens, you may be able to swipe left/right to change the view. To swipe, touch the screen and then quickly move your fingertip/stylus across the screen without lifting your fingertip/stylus. Do not pause on the screen with your fingertip/stylus at the initial point of contact or you may accidentally drag an item instead.

Double-tap:	Quickly tap the screen twice on a webpage or other application screen to zoom (the application must support the double-tap/zoom function). Within the browser, double-tapping a web-page section will cause the browser to zoom and fit that section to the width of the screen.

About the Orientation Sensor

The tablet contains a sensor that will automatically change the orientation of most screens as you rotate the tablet. The sensor works best when the tablet is rotated perpendicular to the ground (i.e., when the tablet is held upright and not fat on its back).

The orientation sensor can be turned on and off in the **Display** settings menu.

Charging the Tablet

The tablet comes with a built-in rechargeable lithium-polymer battery.

Before using the tablet, the battery should be charged fully. The Status Indicator will light green when the battery is charged fully.

To charge the battery:

1. Plug one end of the included power adapter into an AC 100-240V outlet.
2. Plug the other end of the included power adapter into the Power jack on the tablet.
3. Disconnect the power adapter when the tablet is fully charged.

The battery used in this device may present a fire or chemical burn if mistreated. Do not disassemble, incinerate, or heat the device. Do not leave the de-vice in a place subject to direct sunlight, or in a car with its windows closed. Do not connect the device to a power source other than that which is indicated here or on the label as this may result in the risk of fire or electric shock.

Inserting a Memory Card

The tablet accepts microSD memory cards. Insert a memory card into the microSD card slot to:

- ✦ Increase the memory capacity of your tablet
- ✦ Play media files stored on the memory card (e.g., music, video, or photo files).

To insert a memory card:

1. Align the memory card with the card slot. The metal contacts of the memory card should face down away from the LCD screen.
2. Slide the card into the spring-loaded slot. Push the card in until it clicks into place.

> *Do not attempt to insert objects other than a microSD memory card into the card slot. A compatible memory card should fit easily into the card slot; if you encounter resistance, check the alignment of the card. Do not attempt to force the card in.*
>
> *Avoid touching the gold contacts of the memory card.*

To release and remove a memory card:

1. **UNMOUNT the memory card.**
   a. From the home screen, tap the **Menu** key, and then touch Settings to show the settings menu.
   b. Touch **SD card & Device storage** to show the SD card & device storage settings.
   c. Touch **Unmount SD card** to prepare the memory card for safe removal.
2. Push the card further into the slot until you hear a click. The card will spring out of the slot.
3. Grasp the card by its edge to remove it.

> *To avoid damage and data corruption, do not remove a memory card while data is being written to or read from the card. For example, do not remove a card while playing a music file stored on the card.*

English

Getting Started

Turning the Tablet on and off

To turn the tablet on:

- Press and hold the **Power** key until the LCD screen turns on. Wait until the Home screen appears; the tablet is now ready for use.

To turn the tablet off:

1. Press and hold the **Power** key until the Device Options menu appears.



2. Touch **Power off** on the screen. A confirmation message will appear.

3. Touch **OK** to turn off the tablet.

Turning the Screen On and Off (Standby)

When the tablet is on, you can turn off the screen to conserve battery power. Simply press the **Power** key once to turn the screen off. Press the **Power** key again to turn the screen back on.

> *To conserve battery power, the screen can be set to turn off automatically when the tablet is not in use (between 15 seconds and 30 minutes). This* **Screen timeout** *option can be found in the* **Display settings** *menu.*

Unlocking the Screen

When the screen turns off, you will have to unlock the screen when you turn it back on.

To unlock the screen, drag the **lock** icon across the screen towards the speaker icon.



English

If a password has been set, enter the password to finish unlocking the screen. The Screen Unlock password can be set in the **Location and security** settings menu.



Home Screen at a Glance

The home screen is the starting point for all of the features of your tablet.



Name		Description
1	Notification bar	Shows notification icons such as new messages and alarms; drag the bar down to the bottom of the screen to open the full Notifications panel. The right side of the bar also shows status information such as the time, battery level, and network signal strength. *Note: You can press the **Menu** key and then touch **Notifications** to open the full Notifications panel from the Home screen.*
2	Widgets	Widgets are small applications that you can use directly from the home screen. To add widgets to the home screen, touch and hold an empty spot on the home screen; the **Add to Home screen** menu will appear. Touch **Widgets**; then choose a widget from the menu.
3	Launcher Tab	Open the Launcher to view a list of all applications installed on the tablet. Touch the Launcher tab to open the Launcher. *Note: You can swipe left and right to view additional screens.*
4	Icons	Touch an icon to open an application or folder

About Applications

To open an application, touch the application icon on the home screen or in the Launcher.

Launcher screen:



The screen shown above is for illustrative purposes only. MPMAN reserves the right to modify and improve the final list of applications available on the tablet.

English

Preinstalled Applications

Some applications have been installed on your tablet for your convenience. These applications include:

	View the current time, or set an alarm.
	Download and read thousands of e-books. Supports the ePub standard.
	Find and display app installation files (APKs) on your tablet.
	Browse for, download, and install applications from the AppsLib store.
	Browse the web.

	Perform simple mathematical operations.
	Take pictures or videos with the front-facing camera.
	Check your e-mail.
	View photos and play videos.
	Play music.
	Access the Settings menu to adjust the tablet's options.
	Launch the mobile YouTube™ browser page to watch internet videos.

Installing Applications

You can also download an install additional applications from AppsLib, the web browser, or other sources.

The tablet must be set to allow installation of applications from non-Market sources. The Unknown sources option can be set in the **Application settings** menu.

Support for third-party applications is provided by their respective applications developers. MPMAN is not responsible for the behavior of these applications; please review the description and terms of use provided by third-party developers carefully before installing applications on your tablet.

About Menus

There are two types of menus used by the tablet.

1. Option menus.

Option menus contain items related to the current screen or application. To view an option menu, press the **Menu** key.

Not all screens or applications have an option menu; if a menu does not exist, nothing will happen if you press the **Menu** *key.*

English

2. Context menus.

Context menus contain items related to a specific item on the screen. To view a context menu, touch and hold an item on the screen.

Touch & hold **Video(3)**.



A context menu will appear.



Not all items have a context menu; if a menu does not exist, nothing will happen if you touch and hold the item.

About Notifications

The icons that appear in the Notification bar at the top of the screen alerts you when new messages arrive or alarms or other application events occur.

View and respond to the notifications by opening the full Notifications panel.

- Drag the **Notification** bar down to the bottom of the screen to open the Notifications panel from any screen, or;
- On the Home screen, press the **Menu** key and then touch **Notifications** to open the Notifications panel.



1. **To respond to a notification:**

Touch a notification in the list; the Notifcations panel will close and the application associated with the notification will launch.

2. **To clear all notifications:**

Touch the Clear button at the top right of the Notifications panel; the panel will close and all notifications will be cleared.

3. **To close the Notifications panel:**

- Drag the handle at the bottom of the Notifications panel to the top of the screen, or;
- Press the **Back** key.

English

Connecting to the Internet

This tablet can utilize Wi-Fi data networks to connect to the Internet. Wireless Wi-Fi technology can provide Internet access at distances of over 300 feet; however, this distance can be affected by your surrounding environment and Wi-Fi router.

Requirements

In order to connect to the Internet, you will need the following:

1. **A wireless router or access point with a broadband Internet connection**

The wireless router must support Wi-Fi 802.11b/g connections. If the router supports 802.11n, make sure that it has been configured to acc qept 802.11b/g connections as well.

A minimum connection speed of 64 Kbps is recommended. Faster speeds will enable a better Internet experience.

2. **The wireless router network settings**

You will need to know the name of your network (SSID), as well as the password or other credentials if your network is secured. These settings can usually be found on the administration webpage of your wireless router.

Please refer to your wireless router's documentation for help, or ask your network administrator for details.

You may encounter open Wi-Fi networks, or "hot spots." These networks are usually configured so that you can simply connect to them without needing to know its settings; the tablet will obtain all the information it needs from the router automatically.

Connect to a Wi-Fi network

The Notification bar displays icons that indicate your tablet's Wi-Fi status.

	Notification that an open Wi-Fi network is in range.
	Connected to a Wi-Fi network (waves indicate connection strength).
[no icon]	There are no Wi-Fi networks in range, or the Wi-Fi radio is off.

1. **Turn on the Wi-Fi radio if it is not already on. To turn on Wi-Fi:**

   b. Go to the Home screen:

      Press the **Home** key.

   c. Open the Settings menu:

      Tap the **Menu** key, then touch **Settings**.

   d. Open the Wireless & networks menu:

      Touch **Wireless & networks**.

   e. Open the Wi-Fi settings menu:

      Touch **Wi-Fi settings**.

   f. Make sure that the Wi-Fi option box is checked: Touch **Wi-Fi**.



When Wi-Fi is on, the tablet will look for and display a list of available Wi-Fi networks.

If a network that you have connected to previously is found, the tablet will connect to it.

If you don't see your network in the list, you can force the tablet to re-scan. To scan for networks, tap the **Menu** *key, and then touch* **Scan**.

English

2. Select an available Wi-Fi network to connect to:

In the same Wi-Fi settings menu above, touch a network in the list.

If the network is open, the tablet will prompt you to confirm connection to the network. Touch **Connect** to confirm.

If the network is secured (as indicated by a Lock icon), the tablet will prompt you to enter a password or other credentials. Touch the Wireless password box to show the on-screen keyboard and then use it to enter the password. Touch **Connect** to confirm.

When you have successfully connected to a Wi-Fi network, the Notifications bar at the top of the screen will show a Wi-Fi signal indicator.

To learn about how to add a Wi-Fi network when it is not in range or when the router is set to obscure the network name (SSID); or to configure advanced Wi-Fi options, please refer to the manual.

Browsing the Web

The Browser application lets you visit webpages and find information on the web. Keep up with the news, your friends, or enjoy video from YouTube™, the world's most popular video-sharing community.

To use Browser, the tablet must be connected to the Internet. Read the section "Connecting to the Internet" to learn how to connect to the Internet.

To open Browser, touch the Browser icon on the Home screen or in the Launcher.



	Name	Description
1	Address bar	Displays the address (URL) of the current page. Touch the bar to enter a new address or to search the web.
2	Bookmark icon	Touch the **Bookmark** icon to add or view bookmarks, to view your most visited sites, or to view your browser history.

English

Some common Browser actions are described below.

✦ **To go to a webpage.**

1. Touch the **Address bar** at the top of the Browser screen. The keyboard will open automatically. (If the Address bar is not visible, drag the page down to return to the top of the Browser screen.)	7:16 AM www.mpmaneurope.com MPMAN, Inventor of the mp3 player... ... www.mpmaneurope.com q w e r t y u i o p a s d f g h j k l z x c v b n m DEL ?123 / . Go
2. Use the keyboard to enter the ad-dress (URL) of the webpage (e.g., m.youtube.com.	
3. Touch **Go** to open the webpage.	

✦ **To bookmark a webpage**.
Bookmark your favorite webpages in order to visit them quickly without entering a URL.

1. Go to the web-page that you want to bookmark	
2. Touch the **Book-mark** icon to the right of the Ad-dress bar.	
3. Touch the **Add** tile.	

4. If desired, you can modify the name of the bookmark or its location (URL address). Otherwise, touch **OK** to finish adding the bookmark.	

✦ **To go to a bookmarked webpage.**

1. Touch the **Bookmark** icon to the right of the Address bar.	
2. Touch a bookmark tile to open it.	

✦ **To open a new browser window.**

1. Press the **Menu** key to show the Browser options.	
2. Touch **New Window** to open a new browser window.	

English

✦ **To switch between browser windows.**

1. Press the **Menu** key to show the Browser options.	
2. Touch **Windows** to show a list of open browser windows.	
3. Touch the name of a window to switch to it, or touch the “x” to close the window.	

Managing Applications

Downloading and installing new applications to your tablet can extend its functionality in many ways.

You can download and install applications from the included AppsLib store. To open the AppsLib store:

1. Touch the **Launcher** icon.
2. Touch the **AppsLib** icon.



When installing an application, it will tell you what functions of the phone it needs to control and if it needs access to your data. Make sure you review these access requirements carefully before completing the installation.



Be especially cautious with applications that request access to many functions or to a significant amount of your data. You are responsible for the results of applications installed on your tablet.

English

- You can learn more about AppsLib, and browse applications by visiting their website at www.appslib.com.

Some developers allow you to download and install applications directly from their website.

Support for third-party applications is provided by the respective application developer. MPMAN is not responsible for the behavior of these applications; please review the description and terms of use provided by third-party developers carefully before installing applications on your tablet.

To uninstall an application:

1. From the Home screen, tap the **Menu** key.
2. Touch Settings to open the **Settings** menu.
3. Touch **Applications**, and then touch **Manage applications** to show a list of all applications installed on the tablet.



4. Touch the name of the application you want to uninstall; the Application Info screen will open.



5. Touch **Uninstall**. The tablet will prompt you to confirm.



6. Touch **OK** to uninstall the application.

Optional Connections

English

Connecting to a Computer

Connect the tablet to a computer to transfer files.

1. **Connect your tablet to the computer.**

With the included USB cable:

- Plug the small end of the cable into the USB 2.0 Hi-speed connector of the tablet.
- Plug the large end of the cable into an available USB 2.0 Hi-speed port on the computer.

2. **When your tablet is connected, a USB icon will appear in the Notification bar.**

Drag the Notification bar down to open the notifications panel.



3. **Mount the storage drive.**

- Touch USB connected (Internal) to mount the tablet's built-in storage, then touch Mount when prompted to confirm. When mounted, you can copy files to/from your computer to it.
- If a memory card is installed, touch USB connected (External) to mount the card, then touch Mount when prompted to confirm. When mounted, you can copy files to/from the computer to it.

Your tablet will be recognized by the computer as a Removable Storage drive. Drag and drop files between your tablet and the computer. To learn more about copying files, please refer to the documentation included with your computer or operating system.

Connecting to a TV

Connect to a TV to enjoy your tablet from the comfort of your living room. An HDMI cable (Type A-to-Type C) is required to connect the tablet to a TV.

Before connecting the tablet to the TV, you will have to adjust a few display settings on the tablet.

- Make sure that the tablet is set to output over HDMI
- For optimal visual performance, make sure that the video output resolution of your tablet matches the capabilities of the TV.

To adjust the display settings:

1. From the home screen, press the **Menu** key, and then touch Settings to show the settings menu.
2. Touch **Display** to show the Display settings.
3. Touch **HDMI**, and then touch a resolution option that matches the display capabilities of the TV:
    a. Choose **1080P** if your TV is capable of displaying 1080p video.
    b. Choose **720P** if your TV is capable of displaying 720p or 1080i video.

English

To connect the tablet to the TV:

1. Plug the small end of the HDMI cable into the mini HDMI connector of the tablet.
2. Plug the large end of the HDMI cable into the HDMI port on the TV.
3. Turn on the TV, and set its display mode to the HDMI port that the tablet is connected to.

The tablet's display will be output to the TV screen.

If you need help setting the display mode of the TV, please refer to the documentation provided by the TV manufacturer.

If there is no sound from the tablet on your TV, you may need to set the **HDMI switch** *sound settings.*

Connecting Headphones

Connect a pair of headphones (or earphones) to the tablet to enjoy media in private.

Lower the volume level of the tablet before connecting headphones, and then slowly raise the volume to a comfortable listening level.

- The headphones must have a 3.5 mm (1/8 in) plug.
- When headphones are connected, speaker output will be disabled automatically.

Hearing experts advise against the constant use of personal stereos played at high volume. Constant exposure to high volumes can lead to hearing loss. If you should experience ringing in the ears or hearing loss, discontinue use and seek medical advice.

Using the USB Full-Size Adapter

The USB full-size adapter can be used to connect and use USB devices with the tablet. The adapter converts the mini USB port on the tablet into a USB On-the-Go (OTG) connector.

Connecting a Keyboard

For times when you want to type for an extended period of time, you may want to connect a full-size keyboard to the tablet.

Use the included USB full-size (Type A) adapter to connect a keyboard to the tablet.



> *You may also use this connection to add a mouse to the tablet.*
>
> *The adapter supports one connection at a time. To use a keyboard and mouse simultaneously, you will need to add an external USB hub.*

Connecting a Storage Device

Use the included USB full-size (Type A) adapter to connect a storage device to the tablet (e.g., a USB flash memory drive).

> *This connection supports a maximum storage size of 4 GB. For additional storage capacity, a microSD card can be added to the tablet.*

English

Setting the System Options

Open the system settings menu to adjust how the tablet looks and functions.

Many applications will have their own settings; refer to the documentation provided by the application developer to learn more.

To open the Settings menu:

1. From the Home screen, press the **Menu** key.
2. Touch **Settings** to open the Settings menu.

The settings are grouped by category. Touch a category to open and adjust its settings.

Please refer to the manual for a description of the items in the Settings menu.

Specifications

Design, specifications, and manual are subject to change without notice.

Processor	Cortex A8 (1 GHz)	
RAM	512 MB DDR2	
Storage	4GB flash built-in microSD card slot (max. 32GB supported)	
Display	MP724:	7.0" TFT LCD (800 x 480), resistive touchscreen
	MP824:	8.0" TFT LCD (800 x 600), resistive touchscreen
	MP1024:	10.1" TFT LCD (1366 x 768), capacitive touchscreen
Wi-Fi Networking	IEEE 802.11 b/g	
Video Output	Mini HDMI, type C (1080p and 720p supported)	
Audio Output	3.5 mm headphone	
PC Interface	USB 2.0 Hi-speed	

Additional Features	Front-facing camera (0.3 MP) Built-in microphone Stereo speakers	
Operating System	Android™ 2.2	
Power	Rechargeable Li-poly battery Power Adapter (DC 9V, 2A)	
Playback Time (hours) *	MP724:	Up to 14 hours music, 4.5 hours video, 6 hours web browsing
	MP824:	Up to 15 hours music, 4.5 hours video, 6 hours web browsing
	MP1024:	Up to 17 hours music, 4.5 hours video, 6 hours web browsing

* *Music was tested with a 128 kbps MP3 file; video was tested with a 1920 x 1080 MPEG-4/AVC file; browsing was tested with the screen brightness set to default. Actual playback results may vary.*

For more information please check our website

www.mpmaneurope.com

A pleine puissance, l'écoute prolongée du baladeur peut endommager l'oreille de l'utilisateur